




Bottomless Tokens™ 2018



Factory installed
 Zamontowane fabrycznie

Available
 Dostępne

Monteret fra fabrikken
 Namontováno výrobcem

Overskydende
 K dispozici

Εργοστασιακή τοποθέτηση
 Montate din fabrică

Διαθέσιμο
 Disponibile

32 mm Solo Air™
 35 mm Solo Air / DebonAir™
 35 mm Dual Position Air™

Available
B Boost
DPA Dual Position Air

Bluto™			
	80 mm	100 mm	120 mm
26"	 4 Max	 4 Max	 4 Max

BOXXER®

	200 mm
26" 27.5"	 4 Max

Lyrik™ DebonAir

	150 mm	160 mm	170 mm	180 mm
27.5"B	 5 Max	 5 Max	 4 Max	 4 Max
29"B	 5 Max	 5 Max	 4 Max	 4 Max

Lyrik DPA

	150 mm	160 mm	170 mm	180 mm
27.5"B	 6 Max	 5 Max	 5 Max	 4 Max
29"B	 5 Max	 5 Max	 5 Max	 4 Max

PIKE® DebonAir

	120 mm	130 mm	140 mm	150 mm	160 mm
27.5"B	 6 Max	 5 Max	 5 Max	 4 Max	 4 Max
29"B	 6 Max	 5 Max	 5 Max	 4 Max	 4 Max

PIKE DJ™

	100 mm	110 mm	140 mm
26"	 2 Max	 2 Max	 4 Max

PIKE DPA

	150 mm	160 mm	140 mm
27.5"B	 4 Max	 4 Max	 5 Max
29"B	 4 Max	 4 Max	 5 Max

REBA®

	100 mm	120 mm	130 mm	140 mm	150 mm		80 mm	100 mm	120 mm	130 mm	140 mm	150 mm
27.5" 27.5"B						29" 29"B						
	3 Max	3 Max	3 Max	3 Max	3 Max		3 Max	3 Max	3 Max	3 Max	3 Max	3 Max

Revelation

	120 mm	130 mm	140 mm	150 mm	160 mm		120 mm	130 mm	140 mm
27.5"B						29"B			
	6 Max	5 Max	5 Max	4 Max	4 Max		6 Max	5 Max	5 Max

RS-1™

	80 mm	90 mm	100 mm	110 mm	120 mm
26" 27.5" 29"					
	3 Max	3 Max	3 Max	3 Max	3 Max

SID®

	80 mm	100 mm
27.5" 27.5"B 29" 29" B		
	3 Max	3 Max

Yari™ DPA

	150 mm	160 mm	170 mm	180 mm
27.5"B 29"B				
	6 Max	5 Max	5 Max	4 Max

Yari DebonAir™

	150 mm	160 mm	170 mm	180 mm		150 mm	160 mm	170 mm	180 mm
27.5"B					29"B				
	5 Max	5 Max	4 Max	4 Max		5 Max	5 Max	4 Max	4 Max

For Bottomless Token™ installation instructions, find your fork's service manual at www.sram.com/service.

Wskazówki dotyczące montażu Bottomless Token dostępne są w podręczniku serwisowym twojego widelca pod adresem www.sram.com/service.

Se instruktioner til montering af Bottomless Token i brugervejledningen til din forgaffel på www.sram.com/service.

Pokyny pro montáž Bottomless Token najdete v servisní příručce své vidlice na adrese www.sram.com/service.

Για οδηγίες τοποθέτησης Bottomless Token, βρείτε το εγχειρίδιο σέρβις του πηρουσιού σας στη διεύθυνση www.sram.com/service.

Pentru instrucțiunile de montare a șaibelor infinite Bottomless Token consultați manualul de service al furcii de la www.sram.com/service.